




GETTING STARTED

<b>1</b> <b>Fn</b>	Long Press to MUTE/UNMUTE	2 <b>Navigation Menu</b> <b>Home</b> <b>Play</b>	3 <b>Navigation Menu</b> <b>Home</b> <b>Play</b>
<b>MUTE</b>	Press to mute reception and to turn the unit off	<b>Navigation Menu</b>	<b>Home</b>
<b>FM</b>	Tuner/Weather Band Mode: Press to enter into Manual Preset to preset areas again to resume playback	<b>Home</b>	<b>Play</b>
<b>PRESET</b>	Press to enter into Manual Preset to preset areas again to resume playback	<b>Navigation Menu</b>	<b>Home</b>
<b>SRC</b>	Press to toggle and select available sources	<b>Navigation Menu</b>	<b>Home</b>
<b>BT</b>	Press to disconnect and select BT sources	<b>Navigation Menu</b>	<b>Home</b>
<b>EQ</b>	Press to select EQ mode	<b>Navigation Menu</b>	<b>Home</b>
<b>BAND</b>	Press to select band	<b>Navigation Menu</b>	<b>Home</b>
<b>DISP</b>	Press to toggle display	<b>Navigation Menu</b>	<b>Home</b>
<b>AUDIO</b>	Press to enter into audio settings	<b>Navigation Menu</b>	<b>Home</b>
<b>MENU</b>	Press to enter into menu	<b>Navigation Menu</b>	<b>Home</b>




SOURCE MODES




All rights reserved. No part of this publication may be reproduced, distributed, or transmitted in any form or by any means, including photocopying, recording, or other electronic or mechanical methods, without the prior written permission of BOSS AUDIO SYSTEMS INC.

TUNER SETUP

<b>1</b> <b>Fn</b>	Long Press to MUTE/UNMUTE	2 <b>Navigation Menu</b> <b>Home</b> <b>Play</b>	3 <b>Navigation Menu</b> <b>Home</b> <b>Play</b>
<b>MUTE</b>	Press to mute reception and to turn the unit off	<b>Navigation Menu</b>	<b>Home</b>
<b>FM</b>	Tuner/Weather Band Mode: Press to enter into Manual Preset to preset areas again to resume playback	<b>Navigation Menu</b>	<b>Home</b>
<b>PRESET</b>	Press to enter into Manual Preset to preset areas again to resume playback	<b>Navigation Menu</b>	<b>Home</b>
<b>SRC</b>	Press to toggle and select available sources	<b>Navigation Menu</b>	<b>Home</b>
<b>BT</b>	Press to disconnect and select BT sources	<b>Navigation Menu</b>	<b>Home</b>
<b>EQ</b>	Press to select EQ mode	<b>Navigation Menu</b>	<b>Home</b>
<b>BAND</b>	Press to select band	<b>Navigation Menu</b>	<b>Home</b>
<b>DISP</b>	Press to toggle display	<b>Navigation Menu</b>	<b>Home</b>
<b>AUDIO</b>	Press to enter into audio settings	<b>Navigation Menu</b>	<b>Home</b>
<b>MENU</b>	Press to enter into menu	<b>Navigation Menu</b>	<b>Home</b>



AUDIO and SYSTEM SETUP



To avoid battery exhaustion be sure to run the vehicle's engine while using this product. Using this product without running the engine can drain the battery.

RADIO OPERATION

- 1) Press the SRC button to select RADIO
- 2) Press **▶** to MUTE, press again to UNMUTE
- 3) To advance stations press **▶**
- 4) To skip previous stations press **◀**
- 5) Press the **▶** button to display RADIO information
- 6) Press the PRESET button to recall PRESETS 1 - 6

BLUETOOTH OPERATION

**PAIRING & DISCOVERING A NEW BLUETOOTH CONNECTION**

Note: The mobile device must be within 33ft (10m) of the MGR450B for Bluetooth to function properly.

- 1) Power on the MGR450B by pressing and holding down the Power button for 1 second, the Bluetooth icon will start to flash signaling that the MGR450B is now ready for Bluetooth pairing.
- 2) Now that the MGR450B is in pairing mode:

**ANDROID users:**  
 a. Go into the Settings Menu of your ANDROID device  
 b. Enter the Bluetooth Menu and press SCAN  
 c. "Boss Audio MGR450B" will now be display under AVAILABLE DEVICES  
 d. If prompted, enter passcode: "0000"

**IOS users:**  
 a. Go into the Settings Menu of your IOS device  
 b. Enter the Bluetooth Menu and press SCAN  
 c. "Boss Audio MGR450B" will now be display under AVAILABLE DEVICES  
 d. If prompted, enter passcode: "0000"

3) If the MGR450B is not seen, repeat the above steps to refresh the "Device List"  
 4) When the BT connection is successful you will see BT CONNECTED message on the MGR450B LCD display, you are now ready to stream music from your devices favorite media player to the MGR450B

RECONNECTION

- 1) Power on the MGR450B and your last paired device Bluetooth
- 2) The unit will now automatically be reconnected

3) If your device was previously paired with the MGR450B, but it wasn't the last paired device:  
 a. Ensure the device is powered on and ready for pairing  
 b. Press and hold MENU button to manually connect / reconnect to the MGR450B

4) If the device is out of range from the MGR450B, it will disconnect automatically.

5) The MGR450B will reconnect to the device once in range, a confirmation message will be displayed on the LCD

BLUETOOTH STREAMING MUSIC

- 1) Press the SRC button to select BT AUDIO
- 2) Press **▶** to start PLAY, press again to PAUSE
- 3) To skip songs or advance tracks press **▶**, press and hold to FAST FORWARD
- 4) To select the previous track press the button **◀**, press and hold to FAST REWIND

5) Press the **▶** button to display song ID3 information

USB OPERATION

- 1) Press the SRC button to select USB
- 2) Press **▶** to start PLAY, press again to PAUSE
- 3) To skip songs or advance tracks press **▶**, press and hold to FAST FORWARD
- 4) To select the previous track press **◀**, press and hold to FAST REWIND

5) Press the **▶** button to display song ID3 information

AUX-IN/INPUT

- 1) Press the SRC button to select AUX IN
- 2) Press **▶** to MUTE, press again to UNMUTE

Ensure to adjust the level of your devices master volume to 75%